






SET UP & PLAY INSTRUCTIONS



1. Connect the Pump to the Tower:

Simply connect the pump hose to the Boom Tower inflation valve as shown. Use the largest of the connector's two holes. With the connector head in the "open" position, press the connector head onto the valve stem as far as it will go, and lift the thumb lock lever to the "locked" position.

(When finished playing, press the thumb lock lever back to the "open" position and separate from the inflation valve.)



2. Attach Balloons

Using 11" or 12" round latex balloons, stretch the "neck" of the balloon and place it on the Boom Tower's balloon tube, as shown.

IMPORTANT SAFETY NOTICE: Children under 8 can suffocate from uninflated or broken balloons. Adult supervision required while playing with balloons. Keep uninflated balloons from children. Discard broken balloons at once.

3. Pump and Have Fun!

Pump up and down on the Boom Detonator's handle to inflate your balloon. The faster you pump, the bigger your balloon gets until it presses against the Balloon Bursting Arcs. Just a few more pumps and – BOOM! – first to burst is the winner.



For suggestions on fun ways to play Boom Blaster, visit www.Boom-Blaster.com



1612 N Broad Street
Lansdale, Pa 19446
(215) 362 - 7368

44 W Ridge Pike
Limerick, Pa 19468
(610) 489 - 2334