



# MURLIN'S MAGIC

READ CAREFULLY BEFORE OPERATING UNIT

**DO NOT PACK THE UNIT AWAY WET. THE UNIT MUST BE THOROUGHLY DRIED BEFORE PACKING AND STORING.**

NEVER USE REAL SPORTS BALLS - BASEBALLS, FOOTBALLS, ETC; THESE UNITS HAVE BEEN DESIGNED FOR USE WITH SOFT FOAM AND SOFT VINYL COVERED EQUIPMENT.

## Setting it up:

Carefully take the unit out of the bag and lay it out with the black (bottom) side down. Toss Games do not have a floor but unroll so the entrance is facing in the direction you want it. If you are operating the unit outside, the wind needs to be blowing against the back of the unit.

Place the blower on the black floor material and find the Velcro blower opening, which is located on the back or inside of the Frisbee unit (usually the red color). Moon Shot Toss - Blower is located at the back of the unit.

Attach the Velcro on the mouth of the blower to the Velcro on the unit. Turn the blower on. Be sure the material is away from the 2 sides of the blower. The blower draws in its air from the side and will not operate properly if the sides are blocked. The blower cord should be underneath the air tube connecting units. On a windy day have 2 people hold the windward side before you inflate it and then stake down properly.

The Frisbee side will inflate first. Be sure the zippers on the other 2 sides are done up. These zippers should only be undone when you are deflating the unit. Support the Frisbee side during the inflation until the other 2 sides inflate. Keep the tubes running to the other 2 sides as straight as possible. The unit will be free standing when all three sides are fully inflated.

There are D-rings with the rope attached on the top of each side of the unit and D-rings with straps attached to each corner at the bottom of the unit. After the unit is inflated stake these loosely to the ground or tie to sandbags if on a hard surface. You will have to attach a rope to the straps on the bottom to secure with sandbags.

When taking the unit down, turn off the blower, unhook it from the unit and undo the zippers so the unit will deflate quicker.

We have provided you with the following for the Toss Game - 24 Balls to Toss, 12 Floating Balloon Bags, 1 Bag of Balloons.



1612 N Broad Street  
Lansdale, Pa 19446  
(215) 362 - 7368

44 W Ridge Pike  
Limerick, Pa 19468  
(610) 489 - 2334